



MODEL NO. 03.W138
Electro-Mechanical Flasher
Instructions


General Information: Input voltage - +12v
Max. Amp Draw - 4 amps per output
Fuse - Maximum 10 amps

Installation:


Before installation of this flasher, disconnect the battery from electrical system. When selecting a location to mount the flasher, keep in mind that the life of any electronic device is directly dependent on the temperature in which it is operated - the cooler the unit, the longer the life. Select a mounting location that is away from sources of extreme heat.

NOTE: NOT FOR USE WITH LED'S

Wiring for use with Positive switching Lights



Wiring for use with Ground switching Lights



PRODUCTS COMPANY • 804 East Hwy. 248 • Cassville, MO 65625
U.S. and Canada Toll Free Numbers • Phone: 800-641-4098 FAX: 800-526-1240
E-mail: sales@able2products.com WEB: www.able2products.com